


TuneMatic

Automatic Motorized Antenna Controller

ICOM IC-1 INTERFACE SUPPLEMENT

For ICOM: IC-706(all), 7000, 7100, 7200, 7300, rigs that support AH4 tuner
Rev. 1/5/17

THIS INTERFACE AUTOMATICALLY SETS THE POWER OF THE RIG TO 10w CW WHEN TUNING THE ANTENNA, AND WILL AUTOMATICALLY RETURN RIG TO PREVIOUS MODE WHEN TUNING IS COMPLETED. Some Icom rigs may not tune in RTTY mode. Set rig in different mode than RTTY when attempting to tune or store.



a) Connect 4 pin larger Molex type connector to ICOM AH-4 antenna port (one side is pointed).

b) Connect 4 pin PC power style connector to TuneMatic interface port.

c) **Rig may show TUNER indicator on while tuning or operating, this is normal.**

JT Communications Ocala, FL www.tunematic.us 352-236-0744