




TM adapter cable instructions

- 1) Connect female connector into male ICOM-style cable on EZ-Tune.
- 2) Connect male plug into associated TM interface box
- 3) Follow the instructions for the associated interface.



JT Communications 579 NE 44th Ave. Ocala, FL USA
352-236-0744

tunematic.us

rev. A